




BS703T EXPLODED VIEW







BS702-019 Body mount 4pcs




BS702-021 Crown gear 43T 2pcs




BS702-022 Diff case 2pcs




BS702-023 Motor washer 2pcs




BS702-024 Universal joint A 2pcs




BS702-025 Bevel gear 13T 2pcs




BS702-027 B-Head Cross Screw (BM3*25) 12pc




BS702-028 Wheel cup join 2pcs




BS702-029 Diff. Unit




BS702-030 B-Head Cross Screw (BM3*27) 12pcs




BS702-031 B-Head Cross Screw (BM3*15) 12pcs




BS702-032 Chassis




BS702-033 Ball Mount A 8pcs



BS702-036 B-Head Cross Screw (BM3*35) 12pcs
BS702-039 B-Head Cross Screw (BM3*30) 12pcs




BS702-040 Main shaft-A 1pcs




BS702-041 Main shaft-B 1pcs




BS702-042 Slipper hub A




BS702-043 Slipper hub B




BS702-044 Motor mount 1pcs




BS702-045 Motor gear




BS702-046 Centre Gearbox Unit



BS702-047 Antenna mount 1pcs




BS702-048 Pin(φ2*20) 4pcs




BS702-049 Main frame shaft (φ5*85) 2pcs



BS702-054 Shaft drive screw 12pcs



BS702-055 Centre Drive Shaft 2pcs



BS702-056 70T Motor




BS702-057 B-Head Cross Screw (BM3*6) 12pcs




BS702-061 Shock Ball 6pcs




BS702-062 Plastic Ball Cup 12pcs




BS702-063 Pin(2*26) 8pcs




BS702-067 Spring/gear washer /gear mount washer




BS702-068 Screw Callar 8pcs




BS701-036 7.2V mAh Ni-Mh battery




BS933-001 Centre drive shaft-Fr




BS903-012 Rim hub w/pin
2*10 4pcs




BS903-022 Washer for rim 4pcs




Flat cross screw
BS903-065 M2.6*10mm 12pcs
BS903-068 M3*14mm 12pcs
BS903-070 ISO M3*10mm 12pcs




B-head cross screw
BS903-073 M3*12mm 12pcs
BS903-075 M3*16mm 12pcs
BS903-079 M3*10mm 12pcs
BS903-089 $\phi 2*10$ mm 12pcs




BS903-081 Cap Head Hexagon
Screw (HM3*10) 12pcs




BS903-083 Diff. Outdrive 4pcs




Ball bearing
BS903-014 $\phi 6*\phi 12*4$ 2pcs
BS903-016 $\phi 10*\phi 15*4$ 2pcs
BS903-086 $\phi 5*\phi 10*4$ 2pcs
BS903-087 $\phi 12*\phi 18*4$ 2pcs
Washer
BS903-091 $\phi 5.2*\phi 10*0.2$ 12pcs
BS903-088 E-clip $\phi 4*0.6$ mm 12pcs




BS903-093 M4 Nylon
Locknut 6pcs




BS903-094 Double way
ball end 6pcs




BS903-095 Set Screw
(M4*4) 6pcs



BS901-048 E-clip
 $\phi 3*0.6$ mm 12pcs




BS901-050 clip for body
 $\phi 1.0$ 6pcs




BS901-064 Set Screw
(M3*3) 6pcs


Nylon lock nut
BS901-066 M3mm 5pcs




BS901-067 Antenna
pipe w/cap 3pcs




BS902-045 B-Head Cross
Screw (BM3*8) 12pcs




BS902-046 B-Head Cross Screw
(BM2*10) 12pcs




BS902-051 B-Head Cross Screw
(BT3*10) 12pcs



B7011 Receiver




B7050 ESC




B7001 Radio Unit


Optional parts/Upgrade parts




BS903-092 Washer B
($\phi 4.2*\phi 8*0.2$) 12pcs




BS903-097 Diff. gearbox




BS903-104 Diff. unit




BS701-035 Charger for
Ni-Mh battery



BS702-069 Rear drive
shaft -long (upgrade)




BS702-070 Driving/Driven
Gear (metal)




BS702-072 Rear drive
shaft-short (upgrade)



BS704-004A Tire Unit
(chromed) 2pcs



BS703-016 Dogbones
(with metal diff gear)



BS901-080 Crystal 2-one set
BS901-081 Crystal 4-one set
BS901-082 Crystal 6-one set
BS901-083 Crystal 8-one set
BS901-084 Crystal 10-one set
BS901-085 Crystal 12-one set